



**Future Technology Devices International Ltd.**

## **Application Note AN\_132**

# **Re-Assigning COM Port Numbers Using the Windows Registry**

**Document Reference No.: FT\_000196**

**Version 1.0**

**Issue Date: 2009-11-06**

This application note illustrates how to re-assign automatically assigned FTDI COM port numbers using the Windows OS registry.

**Future Technology Devices International Limited (FTDI)**

Unit 1,2 Seaward Place, Glasgow G41 1HH, United Kingdom  
Tel.: +44 (0) 141 429 2777 Fax: + 44 (0) 141 429 2758  
E-Mail (Support): [support1@ftdichip.com](mailto:support1@ftdichip.com) Web: <http://www.ftdichip.com>  
Copyright © 2009 Future Technology Devices International Limited

## **Table of Contents**

<b>1</b>	<b>Introduction .....</b>	<b>2</b>
<b>2</b>	<b>System COM Port Assignment .....</b>	<b>3</b>
<b>3</b>	<b>How to Re-Assign COM port numbers by registry modification .....</b>	<b>4</b>
3.1	Open the OS registry .....	4
3.2	Re-assign the COM Name Arbiter in ComDB .....	7
3.3	Import the modified FTDIUSB registry file .....	10
<b>4</b>	<b>Contact Information .....</b>	<b>14</b>
	<b>Appendix A - Revision History .....</b>	<b>16</b>


## **1 Introduction**

This application note describes how to re-assign the COM port numbers allocated during installation on Windows operating systems by modifying registry entries. The application note provides a walkthrough of manually editing the registry, but the same technique could be employed by a program.

**WARNING: Any edits made to a PC registry may be harmful to the operation of the PC. As such we recommend you create a backup of the registry before making any changes. FTDI cannot be held responsible for any damage done as a result of incorrect manual editing of the registry.**

## 2 System COM Port Assignment

COM ports are assigned to FTDI devices during installation based on the next free port as indicated by the PC registry. In most systems this would imply starting at COM3 as COM 1 and COM2 are usually reserved for legacy COM ports. If COM3 is already in use, the next available COM port index will be claimed. In the case of multiple interface chips, such as the FT2232H or FT4232H, a co-installer is used to claim consecutive COM ports for the interfaces of the device. If three FTDI FT4232H devices are connected to a PC, then 12 COM ports will appear to the operating system. In the example below, the PC has assigned these COM ports with com port numbers from COM3 to COM14.




**Figure 2-1 system COM port assignment**

### 3 How to Re-Assign COM port numbers by registry modification

In the example above, the operating system automatically assigns the 12 COM ports from COM3 to COM14. If it is required to re-assign the COM port numbers without setting each port individually, then the FTDIUSB file in the registry can be used to do this. Follow the procedures below to re-assign COM Port numbers using the operating system registry.

#### 3.1 Open the OS registry

To open the OS registry, select the "Start" button and press the "Run". In the pop-up box that appears, type "regedt32" and press enter to access the registry. This is shown in the figure below.




**Figure 3-1 Accessing the registry**

Within the registry, navigate to the following area to access all FTDI devices:

HKEY\_LOCAL\_MACHINE\SYSTEM\CurrentControlSet\Enum\FTDIBUS.


Select FTDIBUS and then under the “file” pull-down menu select “export” – as shown in the figure below .

This will export the FTDIBUS registry key, sub-keys and values to a file.




**Figure 3-2 Export the FTDIBUS registry to a File**

Right click on this saved file and select "Edit" to the open file, as shown in the figure below.



**Figure 3-3 Edit the registry file**

In the FTDIUSB.reg file, modify the "FriendlyName" and "PortName" in the file for each port which needs to re-assigned.



**Figure 3-4 Modifying the FTDIUSB.reg registry file**

For example to re-assign COM7 to COM17 modify the FTDIUSB.reg file as follows:

Replace FriendlyName from "USB Serial Port (COM7)" to "USB Serial Port (COM17)", and modify PortName from "COM7" to "COM17" at the same time. This will re-assign COM7 to COM17 after registry file has been uploaded (illustrated later).

The same method can be used to modify each port.

**Note:** care should be taken that the same COM port number is not repeated.

## 3.2 Re-assign the COM Name Arbiter in ComDB

If COM3 to COM14 are re-assigned to COM13 to COM24. then it is necessary to free up the unused com ports (COM3~COM12) and allocate the new addition ports COM15~COM24. To do this then it is necessary to modify the ComDB database by using the following procedure.

Open the registry and navigate to the following area of the registry

HKEY\_LOCAL\_MACHINE\SYSTEM\CurrentControlSet\Control\COM Name Arbiter


Then open the "ComDB" as shown in the figure below. The example shows that the original value of "ComDB" is as follows:



[illegible]

The ComDB value is a bit mask of COM ports already allocated. This value is equivalent to COM3~COM14.

The first byte "FF" equates to the com ports COM8~COM1 and indicates that these COM ports are occupied. The second byte "3F" equates to the com ports COM14~COM9 and this indicates that these COM ports are occupied. (**Note that COM1 and COM2 are the COM port of motherboard**).




**Figure 3-5 Editing the ComDB database.**

To allocate the COM port numbers COM13~COM24, it is necessary to modify the ComDB value as follows:

[illegible]

This is shown in the following diagram:



**Figure 3-6 change the value 3**

The first byte "03" is used for COM2 and COM1 of motherboard. COM8~COM3 are not used.

The second byte "F0" is equates to COM12~COM9 that are not used and COM16~COM13 that are occupied.


The third byte "FF" equates to COM24~COM17 which are occupied.

**Note: The first byte controls COM8~1, the second byte controls COM16~9, the third byte controls COM24~COM17 and so on. A value=0 means that the port is not used. A value=1 means that the port is occupied.**

### 3.3 Import the modified FTDIUSB registry file


When the FTDIUSB registry file has been modified it is necessary to import the file back into the registry. To be able to do this a user must have full access control rights to modify it in the registry.

To modify the permissions, right click on the FTDIUSB folder in the registry and select the Permissions to enable the permission for modification – as shown in the figure below




**Figure 3-7 Modifying registry Permissions for FTDIUSB folder**

The following window will appear. Select "full control" then press the OK.




**Figure 3-8 Allow Full Control Access rights to the FTDIUSB registry**

Next import the modified FTDIUSB file. Select Import and choose the modified registry file to import the registry file. This is shown in the following figure:



**Figure 3-9 Importing the FTDIUSB file to the registry**

To check that the procedure has worked, open the device manager and press “Scan for hardware changes”. This should show the new COM port assignments as illustrated in the following figure:



**Figure 3-10 Device Manager showing re-assigned COM port numbers**

---

## 4 Contact Information

### Head Office – Glasgow, UK

Future Technology Devices International Limited  
Unit 1,2 Seaward Place, Centurion Business Park  
Glasgow G41 1HH  
United Kingdom  
Tel: +44 (0) 141 429 2777  
Fax: +44 (0) 141 429 2758

E-mail (Sales) [sales1@ftdichip.com](mailto:sales1@ftdichip.com)  
E-mail (Support) [support1@ftdichip.com](mailto:support1@ftdichip.com)  
E-mail (General Enquiries) [admin1@ftdichip.com](mailto:admin1@ftdichip.com)  
Web Site URL <http://www.ftdichip.com>  
Web Shop URL <http://www.ftdichip.com>

### Branch Office – Taipei, Taiwan

Future Technology Devices International Limited (Taiwan)  
2F, No. 516, Sec. 1, NeiHu Road  
Taipei 114  
Taiwan, R.O.C.  
Tel: +886 (0) 2 8791 3570  
Fax: +886 (0) 2 8791 3576

E-mail (Sales) [tw.sales1@ftdichip.com](mailto:tw.sales1@ftdichip.com)  
E-mail (Support) [tw.support1@ftdichip.com](mailto:tw.support1@ftdichip.com)  
E-mail (General Enquiries) [tw.admin1@ftdichip.com](mailto:tw.admin1@ftdichip.com)  
Web Site URL <http://www.ftdichip.com>

### Branch Office – Hillsboro, Oregon, USA

Future Technology Devices International Limited (USA)  
7235 NW Evergreen Parkway, Suite 600  
Hillsboro, OR 97123-5803  
USA  
Tel: +1 (503) 547 0988  
Fax: +1 (503) 547 0987

E-Mail (Sales) [us.sales@ftdichip.com](mailto:us.sales@ftdichip.com)  
E-Mail (Support) [us.admin@ftdichip.com](mailto:us.admin@ftdichip.com)  
Web Site URL <http://www.ftdichip.com>

### Branch Office – Shanghai, China

Future Technology Devices International Limited (China)  
Room 408, 317 Xianxia Road,  
Shanghai, 200051  
China  
Tel: +86 21 62351596  
Fax: +86 21 62351595

E-mail (Sales) [cn.sales@ftdichip.com](mailto:cn.sales@ftdichip.com)  
E-mail (Support) [cn.support@ftdichip.com](mailto:cn.support@ftdichip.com)  
E-mail (General Enquiries) [cn.admin@ftdichip.com](mailto:cn.admin@ftdichip.com)  
Web Site URL <http://www.ftdichip.com>



## **Distributor and Sales Representatives**

Please visit the Sales Network page of the FTDI Web site for the contact details of our distributor(s) and sales representative(s) in your country.

Vinculum is part of Future Technology Devices International Ltd. Neither the whole nor any part of the information contained in, or the product described in this manual, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. This product and its documentation are supplied on an as-is basis and no warranty as to their suitability for any particular purpose is either made or implied. Future Technology Devices International Ltd will not accept any claim for damages howsoever arising as a result of use or failure of this product. Your statutory rights are not affected. This product or any variant of it is not intended for use in any medical appliance, device or system in which the failure of the product might reasonably be expected to result in personal injury. This document provides preliminary information that may be subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. Future Technology Devices International Ltd, Unit 1, 2 Seaward Place, Centurion Business Park, Glasgow G41 1HH United Kingdom. Scotland Registered Number: SC136640



## Appendix A - Revision History

### Revision History

Version 1.0      Initial release

06/11/2009